



Using the Tile Lifter

1. Wear your personal protective equipment including ear defenders, goggles, protective footwear and gloves.
2. Extra caution must be exercised with stiff flooring and aggressive adhesives as they may cause the tile lifter to move sideways.
3. Keep the cable clear of the cutting blades of the machine.
4. Watch out for signs that vibration may be affecting your hands. If your fingers start to tingle or feel numb, take a short break from using the machine. Exercise your fingers to encourage blood circulation.
5. To reduce the risk of vibration affecting your hands, operate the machine for shorter periods. Keep your hands warm: wearing gloves may help do this.
6. Should the machine vibrate excessively it must be returned to the hire company.
7. If you think the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable or extension lead attached to the tile lifter is damaged, stop using the machine and contact the hire company.
8. Take care not to accidentally remove the plug from the socket
9. Switch off and remove the plug from the socket before leaving the Tile lifter unattended.
10. If your equipment does not work properly do not attempt to repair it. Contact the hire company.
11. You may want to read this leaflet again. Please keep it until you finish work.

Keep this leaflet safe as it may be required for reference at a future date



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

1. Use a residual current device ("rCD") plugged directly in to the 230volt socket. Plug your machine into the rcd. This will help to protect you against electric shock if the cable or machine get damaged.

2. Use the "TEST" button to check that the rcd is working each time you use it. Reset the rcd according to the instructions supplied with it.

3. If you need an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, you should only use a suitably rated heavy duty cable, not longer than 50 metres (160 feet).

4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

5. Make sure that any extension cable connections are dry and safe.

6. Should the machine vibrate excessively it must be returned to the hire company.

7. If you think the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable or extension lead attached to the tile lifter is damaged, stop using the machine and contact the hire company.

8. Take care not to accidentally remove the plug from the socket

9. Switch off and remove the plug from the socket before leaving the Tile lifter unattended.

10. If your equipment does not work properly do not attempt to repair it. Contact the hire company.

11. You may want to read this leaflet again. Please keep it until you finish work.

Keep this leaflet safe as it may be required for reference at a future date

Tile Lifter

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read all of this leaflet

BEFORE you use the Tile Lifter

1. Electricity can be hazardous and must always be used with great care.
2. Plan your work and think ahead to make sure that you will always be working safely.
3. The main application for this machine is to remove bonded floor covering in dry environments. It should not be used for any other purpose.
4. The action of this tile lifter can cause injury or damage if the equipment is not used in a careful and controlled way.
5. Plan your work and think ahead to make sure that you are always working safely - Read the recommendations in the "Using the tile lifter" section of this leaflet.
6. You must have at least the following items of personal protective equipment (ppe):
Goggles to a minimum of EN166 B
Respirator (Dust Mask) to a minimum of EN149 ffp2
Boots or protective footwear to a minimum EN345
Ear muffs giving protection for levels up to 101 dB(a)
Gloves
Note - EN number represents European Safety Standard
7. This tile lifter must not be used by minors, or by anyone under the influence of drugs or alcohol.
8. This tile lifter is designed to be used by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before doing so.
9. Exercise caution whilst loading this machine; in particular into and out of your vehicle as its weight is unevenly distributed. Observe good lifting practice and, where possible, share the load.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

©Copyright Hire Association Europe April 2011

1. Do not use this tile lifter where there is a danger of explosion. It will ignite fumes from petrol, or gas cylinders.

2. Do not use this tile lifter in the rain or where the electrical parts might get wet.

3. Protect other persons from the noise and potential harm and ensure your working area is clear.

4. Before starting work clear the area from dirt and debris and other obstacles that could affect your route or damage the blades.

5. Before starting work the flooring requires cutting into strips the same width as the machine's blades.

6. It is recommended that you cut the first strip at right angles to the main working direction: this will make access to the next strips easier.

7. If the floor covering is bonded with a resin, smaller strips should be cut.

8. The following items of personal protective equipment (ppe) must be used as a minimum.

9. You must wear eye protection to a minimum level of protection equivalent to EN 166B.

10. This equipment is likely to cause noise levels up to 101dB(A) - wear appropriate ear protection for this level.

11. You will need to wear an appropriate respirator (dust mask) with a minimum level of protection equivalent to EN149 FFP2.

12. Wear safety boots or protective footwear to a minimum level of protection equivalent to EN345.

13. Always ensure that you operate the tile lifter with two hands.

14. Ensure that you check the on/off switch for location and operation before commencing work.

15. YOU MUST ensure that the machine is switched off and the plug is removed from the socket before removing any waste that power the machine from a standard 240 volt supply.

16. The following items of personal protective equipment (ppe) must be used as a minimum.

17. You must wear eye protection to a minimum level of protection equivalent to EN 166B.

18. This equipment is likely to cause noise levels up to 101dB(A) - wear appropriate ear protection for this level.

19. You will need to wear an appropriate respirator (dust mask) with a minimum level of protection equivalent to EN149 FFP2.

20. Wear safety boots or protective footwear to a minimum level of protection equivalent to EN345.

21. Electricity can be hazardous and must always be used with great care.

22. Plan your work and think ahead to make sure that you will always be working safely.

23. The main application for this machine is to remove bonded floor covering in dry environments. It should not be used for any other purpose.

24. The action of this tile lifter can cause injury or damage if the equipment is not used in a careful and controlled way.

25. Plan your work and think ahead to make sure that you are always working safely - Read the recommendations in the "Using the tile lifter" section of this leaflet.

26. You must have at least the following items of personal protective equipment (ppe):
Goggles to a minimum of EN166 B
Respirator (Dust Mask) to a minimum of EN149 ffp2
Boots or protective footwear to a minimum EN345
Ear muffs giving protection for levels up to 101 dB(a)
Gloves
Note - EN number represents European Safety Standard

27. This tile lifter must not be used by minors, or by anyone under the influence of drugs or alcohol.

28. This tile lifter is designed to be used by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before doing so.

29. Exercise caution whilst loading this machine; in particular into and out of your vehicle as its weight is unevenly distributed. Observe good lifting practice and, where possible, share the load.



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

1. If using a portable transformer, plug the transformer directly into the 230 volt socket. Do not use any 230v extension cables.

2. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, you should only use a suitably rated heavy duty 110v extension cable, not longer than 50 metres (160 feet).

3. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

4. Make sure that any extension cable connections are dry and safe.

5. Use the "TEST" button to check that the rcd is working each time you use it. Reset the rcd according to the instructions supplied with it.

6. If you need an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, you should only use a suitably rated heavy duty cable, not longer than 50 metres (160 feet).

7. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.

8. Make sure that any extension cable connections are dry and safe.

9. Switch off and remove the plug from the socket before leaving the Tile lifter unattended.

10. If your equipment does not work properly do not attempt to repair it. Contact the hire company.

11. You may want to read this leaflet again. Please keep it until you finish work.

Keep this leaflet safe as it may be required for reference at a future date



Before Starting Work...