Using the Submersible Pump

- Switch off from the mains supply and remove the plug before lifting it out of the
- Lift the pump from the water by the rope attached to the lifting ring. Do not lift by the electrical cable.
- Keep the suction inlets on the pump clear of rubbish or mud.
- If the pump is blocked, switch off and unplug before trying to clear it.
- Make sure the cable does not get trapped on any sharp edges.
- If you think the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it. If the cable attached to the submersible pump is damaged, stop using the equipment. Contact the hire company.
- If an extension cable has been damaged, do not use it again.
- Take care not to accidentally pull the plug from the socket.
- Switch off and remove the plug from the socket before leaving the pump
- 10. If your equipment does not work properly do not attempt to repair it. Contact the hire company.
- 11. You may want to read this leaflet again. Please keep it until you finish work.

Please keep this leaflet safely as it may be required for future reference















©Copyright Hire Association Europe April 2011

Any unauthorised reproduction - manually or electronically - is STRICTLY prohibited

1401 Submersible pump -110/230v



Submersible Pump

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the submersible pump

- Electricity is dangerous and must always be used with great
- 2. Electricity and water can make a hazardous combination. Keep electrical equipment away from rain and water, unless it is specially designed for such use.
- This submersible pump is designed for partial or total immersion in water to be pumped.
- The action of this submersible pump can cause damage and possibly injury if the equipment is not used in a careful and controlled way.
- If you have not used a submersible pump before, familiarise yourself with the equipment before you start the main task.
- Plan your work and think ahead to make sure you will always be working safely.
- You should have at least the following items of protective equipment: rcd if using a 230 volt (mains) supply.
- This equipment must not be used by minors, or by anyone under the influence of drugs or alcohol
- This submersible pump is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.













ading. HAE/EHA cannot accept responsibility for any loss or liability p to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can a

> ммм.пае.огд.ик mali@nae.org.uk :lismal 44 (0) 121 380 4600

2450 Regents Court The Crescent Birmingham Business Park Solihull B37 7YE



socket. Do not use any 230v extension

directly into the 230 volt bing the transformer transformer, bouggpie 1. If you are using a

PLUG)


110 VOLT MACHINES (YELLOW

10r your equipment. industrial plug. Read the instructions below normal square pin plug titted, or a blue fitted. 230v equipment will have either a ednibment will nave a yellow industrial plug voltage: It will be 110v of 230v. 110v Your equipment will only operate on one

ELECTRICAL SAFETY

fitted, or a blue industrial plug.

will have either a normal square pin plug designed to run directly from 230v mains be heavier than you think. Equipment yourself when moving it about - it may been supplied, take care not to injure



supply. It a portable transformer has

matches your supply. Do not try to use Check that the plug on your equipment

company.

rue snowersible pump - contact rue nire anyming is round damaged, do not use 1. Check your pump, cables, and plugs. If


20BMERSIBLE PUMP

Warn others to keep away. Put up Protect other people from the danger.

oue is uear to you or could distract you. the area is clear and safe and that noruere is a risk of falling in make sure that 5. If you are pumping from water where

ignite fumes from petrol, or gas there is a danger of explosion. It will Do not use this submersible pump where

MORK AREA



PIN OR BLUE PLUG) 230 VOLT MACHINES (SQUARE

connections are dry and sate. 4. Make sure that any extension cable

could catch fire. over it. Unroll it fully or it will overheat and and places where vehicles might run or windows where it might be trapped, avoiding liquids, sharp edges, doorways 3. Lay the extension cable out carefully

transformer and equipment. use an extension cable between the than 50 meters (160 feet). You must only duty 110v extension cable, not longer should only use a suitably rated heavy follow any special instructions, you If you need to use an extension cable,















rcd is working each time you use it. 2. Use the "TEST" button to check that the cable or equipment gets damaged. brotect you against electric shock if the

Reset the rcd according to the instruction

connections are dry and safe.

2. Make sure that any extension cable

fully or it will overheat and could catch

where vehicles might run over it. Unroll it

where it might be trapped, and places

suarp edges, doorways or windows

duty one, not longer than 50 meters (160

eponia only use a suitable rated heavy

diven any special instructions, you

4. Lay it out carefully avoiding liquids,

teet). Plug it directly into the rcd.

company. If the hire

given by the hire

su) special instructions

extension cable, follow

3. If you need an

supplied with it.